

eco



talknanoPRO

WIRELESS BLUETOOTH HEADSET

USERMANUAL



About Bluetooth technology

Bluetooth wireless technology has revolutionised personal connectivity by providing freedom from wired connections. It has enabled wireless communication and connectivity between computers, mobile phones, portable handheld devices and other Bluetooth-enabled devices within a range of 10 metres.

Contents:

| | |
|----------------------------|-------|
| Introduction | 4 |
| Charging | 5-6 |
| Basic Operation | 7-8 |
| Specifications | 9 |
| Nexus Warranty Information | 10-11 |


Introduction

Thank you for purchasing the Nexus Talknano PRO. Your Bluetooth headset can be used with any Bluetooth-enabled mobile phone or device. This gives you the freedom of wireless technology as well as the safety and convenience of wireless hands-free communication, especially whilst driving.

Please read this user manual carefully before using your headset. Please refer to your mobile phone's user manual regarding its Bluetooth functions and pay attention to important safety and maintenance information. Keep the headset away from children.

[Note]: For the user manual, all rights are reserved to the manufacturer.

- 1 Ear Hook
- 2 Ear Cap
- 3 Volume Down Key (VL-)
- 4 Volume Up Key (VL+)
- 5 LED Indicator Light
- 6 Multifunction Button(MFB)
- 7 Charging Socket
- 8 Speaker
- 9 Microphone



Charging

BATTERY INFORMATION

This headset is powered by an internal rechargeable battery.

The new battery will achieve its best function only after it is fully charged and discharged two or three times. Normally the battery life will run out after being charged and discharged several hundred times. Please only use the designated headset charger supplied with the headset to charge the battery.

If left unused, a fully charged battery will lose its power automatically. Please try to charge the battery every three months if you don't use the headset for a long time.

Do not to expose your headset to extremes in temperature. Ideal operating temperature is between 15 °C and 25 °C. Exposure to temperature extremes will reduce the capacity and lifetime and performance of the battery. The battery performance will be particularly limited when the temperature is below freezing.


Do not dispose of the battery into a fire as they may explode. Please dispose of the battery according to your local regulations. Please recycle the battery when possible. Do not dispose of the battery as household waste.

CHARGING INFORMATION

- 1 Before you use the headset, you must charge its battery, then pair the headset with a compatible phone.
- 2 Please check the charger model number to make sure it is for this headset before charging.
- 3 Please only use the batteries and chargers approved by Nexus. Using chargers other than the ones supplied will invalidate your product warranty and may be dangerous.
- 4 The headset has one built-in rechargeable battery and is non-removable. Never attempt to take the battery out of the headset.
- 5 When the battery is out of power, the headset will beep and the red LED will flash. Please charge the headset right away.

CHARGING STEPS

- 1 Connect the charger to the headset.
- 2 The red indicator light turns on during charging.
- 3 The red LED will turn off automatically once the headset is fully charged. The charging time is about 2-3 hours.



Basic Operation

TURNING ON THE HEADSET

Press the Multifunction Button (MFB) until the headset beeps and the blue LED starts to flash.

TURNING OFF THE HEADSET

Press the Multifunction Button (MFB) until the headset beeps and the LED light turns off.

PAIRING THE HEADSET WITH A COMPATIBLE PHONE OR DEVICE

- 1 Make sure the headset is off.
- 2 Turn on your phone and activate the Bluetooth function on your phone.
- 3 Press and hold the Multifunction Button (MFB) until the blue LED and red LED flash in turn.
- 4 Activate the search/discovery function on your mobile phone or device.
- 5 Once the search has finished, select 'Talknano' from the list of found devices.
- 6 Enter the pass key '0000' to pair and connect the headset to your phone or device.

ANSWERING A CALL

To answer a call, press the headset MFB.

ENDING A CALL

To end the current active call, press the headset MFB.

REJECTING A CALL

If you do not want to answer a call, press the headset MFB for 2 seconds until it beeps.

REDIALING

Please press the headset's MFB twice.

VOICE DIALING

Press the headset MFB.

ADJUSTING THE VOLUME

Press the VL+ key to increase or the VL-key to decrease the volume.

DISCONNECTING

To disconnect the paired headset from your phone, just turn off the headset or disconnect the headset from the Bluetooth menu of your phone.

SPECIFICATIONS

| | |
|-----------------------|--------------------------------------|
| Model No | Talknano PRO |
| Bluetooth Version | V2.0 + EDR |
| Frequency | 2.4GHz~2.4835GHz ISM Band |
| RF Output Power | 0dBm |
| Headset Passkey | 0000 |
| Operation Range | Up to 10 meters(30 feet) |
| Battery | 3.6V rechargeable Li-polymer battery |
| Voltage | DC 5.0V~6.5V |
| Operating Temperature | -10°C~+45°C |
| Dimensions(mm) | L33XW15XH10 |
| Weight | 7g |
| Talking Time | Up to 4 hours |
| Standby Time | 140 hours |

*Bluetooth is a registered trademark of Bluetooth SIG, Inc.

*Patented product, any imitation or counterfeiting will be pursued legally.

Nexus warranty information

Nexus offers a limited warranty for this product against any defects in material and workmanship for a period of one year from the date of purchase by the end user/consumer. The conditions of the warranty are as follows:

- The warranty is only valid upon presentation of the original receipt (from dealer/retailer) by the original purchaser with the product to be repaired or replaced.
- The warranty is void if the serial number, date of purchase and label has been removed.
- The warranty does not cover damage or product failure resulting from normal wear and tear, physical abuse, improper installation, misuse, modification or repairs by unauthorised third parties.
- Nexus does not assume responsibility for any loss or damage incurred during shipment or as a result of a force majeure.
- Nexus is not liable for any incidental or consequential damages arising from the use or misuse of this product.
- All warranty claims are limited to repair or replacement of the defective product and at the sole discretion of Nexus.

- If Nexus repairs or replaces the product, the product will be covered for the remaining time of the original warranty period. Repair or replacement may involve the use of reconditioned units which are equivalent in function. Replaced part or product becomes the property of Nexus.
- Consumable components such as batteries are not covered by the warranty.

For customer support please visit: www.nexus.co.uk

The Nexus brand is owned by Shebang Distribution Limited.



WEEE Directive 2002/96/EC Art.11(2)

The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly you will help prevent potential negative consequences for the environment and for human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local council office or your household waste disposal service.

nexus
ACCESSORIES